

RNase Displace™

Technical Data Sheet

- BRIEF DESCRIPTION -

RNase Displace removes RNase, and unwanted DNA. It works instantly so there is no waiting. RNase Displace eliminates the time-consuming method of autoclaving. RNase Displace can be used on all surfaces including glass, plastic, metal, and ceramic. RNase Displace is phosphate-free, safely disposable, non-toxic, and totally rinsable for the decontaminated surface.

- USE PROCEDURE -

Use RNase Displace full strength.

Method 1: Thoroughly wet item to be decontaminated with RNase Displace - ensure all surfaces are coated. Swirl for a few seconds, drain, and immediately rinse twice with the RNase-free water.

Method 2: Soak item in RNase Displace until needed. Drain and rinse as above.

Method 3: Soak an RNase-free wipe in RNase Displace, wipe over surface to be decontaminated. Rinse as above.

For total radioactive decontamination, soak item in RNase Displace for 2-12 hours. Rinse as above. Wipe over benchtops and sinks to remove residual contamination.

- CAUTION -

Alkaline! Severe eye irritant, mild skin irritant. Wear eye and skin protection when handling RNase Displace. In case of contact with eyes, immediately flush with water for fifteen minutes and contact a physician immediately.

- PACKAGING -

250 mL (8 oz.) / 12 per case 950 mL (32 oz.) / 12 per case

One Gallon / 4 per case

- CATALOG NUMBERS -

<u>Item</u>	Fisher Cat. No.	FoxWest Sales Cat. No.
8 oz.	04-355-137	1408
32 oz.	04-355-138	1432
1 gallon	04-355-136	1401

For Additional Technical Information call FoxWest Sales Customer Service (800) 332-6647, or See our website at www.deconlabs.com

FoxWest Sales, Inc. Revised 12/05/2014